

Tel: 01382 480842 Fax: 01382 480323 info@ravensbyglass.co.uk www.ravensbyglass.co.uk

BIOCLEAN® has been specially designed to remain cleaner for longer than conventional glass. A transparent coating on the external surface of the glass harnesses the power of ultra – violet rays and the rain to break down dirt and grime then wash it clean away.

The coating is totally integrated into the surface of the glass and is highly durable. However, as with all coated glass, certain guidelines must be followed to ensure correct installation and proper maintenance of this product.

These instructions must be followed carefully in order to maintain the special properties of this glass.

BIOCLEAN® is delivered with a special label affixed to the coated surface. This label must remain attached until it is received on site. It should then be carefully removed at first clean-down.

As with all coated glasses BIOCLEAN® must be stored in a clean, dry, ventilated area, protected from any extreme variations in temperature and humidity. The product should also be stored away from areas where there is silicone present.

## Receipt of glass



- Avoid all contact or friction with sharp, metal or abrasive objects which may scratch the special coating (e.g. belt buckles. Stanley Knives, razors).
- Avoid contamination from hands which have been in direct contact with silicone. Use clean, dry, cloth safety gloves. Avoid those with rubber or silicone grips.
- Hand held or machine suckers must be in a good condition, clean and completely silicone-free.
- In order to ensure their cleanliness protective covers are recommended

## Assembly into frame



- Always position the coated surface facing outward to the exterior. The coated face can be identified by the presence of a special BIOCLEAN® label.
- Avoid all contact with linseed oil and silicones during assembly and installation (including setting blocks, grease or silicone sealants, adhesives, glues, lubricants).
- Glazing tapes used in timber frames should not be capped with silicone.
- The use of pre-formed or dry gaskets (such as EPDM gaskets) is recommended with this product.



Ensure that hand-held suckers are clean and in good condition.

Please do not hesitate to contact us for further information.